

BSI No.:G16B184Publish Date:03/11/2016Subject:Release of TOSHIBA Viewer V2 (Ver.1.07) for e-STUDIO243/245 Series

Model: e-STUDIO223, e-STUDIO243, e-STUDIO195, e-STUDIO225, e-STUDIO245

Category	Field Application	UNIT
C28 Addition of the Supported OS/Application	F03 To be applied when problem happens	U53 Application Software, U81 Printer driver, U83 Scanner driver (TWAIN)

FactoryApplication: Applied in the field

Parts Availability in Tokyo:

<u>CONTENT</u>

We would like to inform you of a release of TOSHIBA Viewer V2 (Ver1.07).

1. Release Content

1. Windows 10 have been supported.

2. Windows XP(32bit, 64bit), Windows Server 2003(32bit, 64bit) have been removed from the supported OS.

Support OS: Windows Server 2008 32bit/64bit Windows Server 2012 Windows Server 2012R2 Windows Vista 32bit/64bit Windows 7 32bit/64bit Windows 8 32bit/64bit

Windows 8.1 32bit/64bit Windows 10 32bit/64bit

Applicable languages:

English, Japanese, French, Italian, German, Spanish, Dutch, Hungarian, Czech, Swedish, Norwegian, Finnish, Danish, Polish, Greek, Portuguese, Chinese, Russian

<u>How to install:</u> Refer to the Operator's Manual for installation.

Note:

Use a USB2.0 Hi-Speed cable, which is certified by USB Implementers Forum and supports the USB 2.0 Hi-Speed mode.

2. Applicable Model

Applicable models for fields:

Model

e-STUDIO195/223/225/243/245

3. Supported OS

OS		
Windows Server 2008 32bit/64bit		
Windows Server 2012		
Windows Server 2012R2		
Windows Vista 32bit/64bit		
Windows 7 32bit/64bit		
Windows 8 32bit/64bit		
Windows 8.1 32bit/64bit		
Windows 10 32bit/64bit		

4. Combination of ROM Versions

4-1. Combination of ROM Versions

Refer to the attached file **ToshibaViewerV2_ROM_Combination_CJIV_E.pdf** .

4-2. Combinations of Nonoperating Software Versions

The operation is not guaranteed for the combination of versions earlier than the ones described in "4-1. Combination of ROM Versions".

5. Restriction

Restriction in creating a shortcut (Japanese, Chinese and Taiwanese only)

[Phenomenon]

If you select [Send] in [Output method] and enter an e-mail address in [Recipients] to create a shortcut by clicking its icon on the menu bar, the subject of the e-mail sent from the shortcut will be garbled.

[What to do]

Create a shortcut without entering mail address in [Recipients].